



MC-01 50CC

MC-01 ZN50QT-A(小龟王四冲50碟刹)零部件清单						
零件编号	photo	Description	qty			
50QT-A-000001		上下钢珠 upper/lower steel ball	1	set	G	
50QT-A-000002		上下钢碗 upper/lower race	1	set	G	
50QT-A-000003		前叉紧锁螺母 lock nut, Fr fork	2	pcs	G	
50QT-A-000004		吊架螺栓 I Bolt	1	pcs	H	
50QT-A-000005		吊架螺栓 II Bolt	1	pcs	H	
50QT-A-000006		安全帽挂钩 helmet hook	1	pcs	A	
50QT-A-001001		左后视镜 Rr mirror assy	1	pcs	C	
50QT-A-001002		右后视镜 Rr mirror assy	1	pcs	C	
50QT-A-002000		座垫 seat assy	1	set	A	
50QT-A-003000		载物架 carrier plate	1	pcs	F	
50QT-A-010001		前轮轴 fr axle	1	pcs	H	
50QT-A-010002		前轮衬套 fr wheel bush	1	pcs	G	
50QT-A-010003		碟刹泵线夹 cable cleat, disc brake pump	1	pcs	G	
50QT-A-010004		里程线夹 rubber ring	1	pcs	G	
50QT-A-010101		方向柱 pole steering	1	pcs	G	
50QT-A-010102		前左减震 fr shock absorber	1	pcs	G	

50QT-A-010103		前右减震	rr shock absorber	1	pcs	G
50QT-A-010201		前轮钢圈	Fr tire steel ring	1	set	F
50QT-A-010202		气门嘴	value mouth	1		F
50QT-A-010203		前制动盘	Fr brake plcate	1	pcs	G
50QT-A-010204		碟刹盘螺丝M8X35	Dis brake srew M8X35	3	pcs	G
50QT-A-010205		外胎3.00-10	Tire IRC 3.00-10	2	pcs	F
50QT-A-010300		传动器	Gear Box Assy	1	set	G
50QT-A-010400		前轮挡泥板支架	front wheel fender frame	1	pcs	F
50QT-A-010501		前挡泥板前部	Fr fender Fr	1	pcs	D
50QT-A-010502		前挡泥板装饰件	Chrome plated On front cover	1	pcs	A
50QT-A-010503		前挡泥板后部	Fr fender Rr	1	pcs	D
50QT-A-020101		方向把	handle steering	1	pcs	F
50QT-A-020102		方向把镀铬件	plate chorme, handle steering	1	pcs	A
50QT-A-020103		方向把座	Stem steering	1	pcs	F
50QT-A-020104		上压块	Holder ,hander upper	1	pr	A
50QT-A-020105		下压块	Holder, hander lower	2	pr	A
50QT-A-020200		左闸把组合	Lever assy, brake LH	1	set	

50QT-A-020300		后刹线	Rr brake cable	1	pcs	B
50QT-A-020400		仪表组件	Speedometer Assy	1	set	B
50QT-A-020500		里程线	speedometer cable	1	pcs	B
50QT-A-020600		前碟刹总成	Rr disc brake pump	1	set	G
50QT-A-020700		右组合开关	Right switch assy	1	set	B
50QT-A-020800		油门线	thorttle cable	1	pcs	B
50QT-A-020800		油门转把	accelerograph turning cover	1	pcs	B
50QT-A-020001		左把手套	L handle cover	1	pcs	B
50QT-A-020002		方向把镀铬件装饰灯	chrome decorative light, handle	1	pcs	A
50QT-A-020003		装饰灯安装座	decorative light, fixing seat	1	pcs	
50QT-A-030001		套锁	lock assy	1	set	B
50QT-A-030002		单撑拉簧	Single support haul spring	1	set	G
50QT-A-030003		单撑螺栓	Single support bolt	1	pcs	H
50QT-A-030100		车架	frame	1	pcs	F
50QT-A-030200		喇叭支架	stay leg shield	1	pcs	F
50QT-A-030400		单撑	stand comp, side	1	pcs	F
50QT-A-030501		吊架	hanger comp engine	1	pcs	F


50QT-A-030502		吊架缓冲套	hanger rubber sheath	1	pcs	B
50QT-A-030600		座垫锁支架	Seat bracket	1	pcs	F
50QT-A-030700		后货架支架	Bracket rear carrier	1	pcs	F
50QT-A-030800		油箱压板	Bracket, oil box	1	pcs	F
50QT-A-040100		发动机	engine	1	pcs	I
50QT-A-040201		后轮钢圈	Rr tire steel ring	1	pcs	F
50QT-A-040300		后刹车蹄块	Rr brake shoe	1	pcs	G
50QT-A-040400		消声器	muffler	1	pcs	G
50QT-A-040500		后减震	Rr cushion	1	pcs	G
50QT-A-040601		空滤器总成	air cleaner assy	1	set	A
50QT-A-040602		空滤器进气管	second-buring filter	1	pcs	A
50QT-A-040700		化油器	carburetor	1	pcs	J
50QT-A-040800		后轮挡泥板(带支架)	Rr wheel fender(frame)	1	pcs	A
50QT-A-040900		大撑	stand assy, main	1	pcs	F
50QT-A-040001		后轮摇臂轴	arm collar, Rr wheel	1	pcs	G
50QT-A-040002		后刹车摇臂	sewing arm, Rr brake	1	pcs	G

50QT-A-040003		二次燃烧过滤器	air colander enterwindpipe	1	pcs	J
50QT-A-040004		通气管组件	ventilate pipe groupware	1	pcs	J
50QT-A-040005		石棉垫	Washer	1	pcs	G
50QT-A-040006		大撑拉簧	spring, main stand	1	pcs	G
50QT-A-040007		大撑橡皮	rubber, main stand	1	pcs	B
50QT-A-040008		大撑衬套	big maintain spring	2	pcs	H
50QT-A-050001		车架挡泥板	frame fender	1	pcs	A
50QT-A-050002		脚踏板	footplate	1	pcs	A
50QT-A-050003		电瓶盖	cap, battery	1	pcs	A
50QT-A-050004		脚踏毯	mat, foot	1	pcs	C
50QT-A-050101		前大板	Fr cover	1	pcs	D
50QT-A-050102		大灯罩	cover, headlight	1	pcs	B
50QT-A-050103		前照灯总成	Headlamp assy	1	set	B
50QT-A-050104		大灯罩装饰件	eadlight cover decorative piece	1	pcs	A
50QT-A-050105		前大板装饰件	Fr cover decorative piece	1	pcs	A
50QT-A-050201		前挡风板	Front shield	1	pcs	D
50QT-A-050202		挡风板左装饰块	Adorn cover, LH	1	pcs	A

50QT-A-050203		挡风板右装饰块	Adorn cover, RH	1	pcs	A
50QT-A-050204		车架号码盖	number cover	1	pcs	D
50QT-A-050205		杂物箱前罩	center cover	1	pcs	D
50QT-A-050206		前转向灯左按装座	front turnig light left fixing sea	1	pcs	D
50QT-A-050207		前转向灯右按装座	ont turnig light right fixing se	1	pcs	D
50QT-A-050208		前转向灯	Fr winker assy	1	pr	B
50QT-A-050301		杂物箱	luggage box	1	pcs	A
50QT-A-050302		杂物箱内盖	inner cover, luggage box	1	pcs	A
50QT-A-050303		座垫支架	Seat bracket	1	pcs	F
50QT-A-050401		左装饰板	L body side cover	1	pcs	D
50QT-A-050402		后转向灯	Rr winker assy	1	pr	B
50QT-A-050403		右装饰板	R body side cover	1	pcs	D
50QT-A-050404		右装饰板盖	Cap,R body side cover	1	pcs	D
50QT-A-050405		侧反射器底座	Plate of side Reflector	1	pr	A
50QT-A-050406		侧反射器	Side Reflector	1	pr	A
50QT-A-050501		后装饰板	Rr body side cover	1	pcs	D
50QT-A-050502		后挡水板	Rear breakwater	1	pcs	A

50QT-A-050503		后尾灯	tail right	1	set	B
50QT-A-050504		尾灯缓冲垫	Cushion,taillight	1	pcs	
50QT-A-050505		后反射器	rear reflector	1	pcs	A
50QT-A-050506		后牌照支架	bracket lense plate	1	pcs	F
50QT-A-060001		传感器压板	sensor press board	1	pcs	B
50QT-A-060002		传感器密封圈	sensor airproof circle	1	pcs	B
50QT-A-060003		汽油管(带保护弹簧)	gasoline pipe	2	pcs	B
50QT-A-060004		负压管	Vacuum tube	1	pcs	B
50QT-A-060005		卡簧	block spring	1	pcs	B
50QT-A-060100		油箱	Fuel tank	1	pcs	A
50QT-A-060200		汽油传感器	fuel sensor	1	pcs	B
50QT-A-060300		油箱盖	cap, fuel tank	1	pcs	A
50QT-A-060400		自吸开关	self-priming switch	1	pcs	B
50QT-A-060500		汽油过滤器	fuel filter	1	pcs	B
50QT-A-070100		主电缆	wire harness, main	1	pcs	B
50QT-A-070200		电瓶	battery	1	pcs	C
50QT-A-070300		高压包	coil comp, ignition	1	pcs	B

50QT-A-070400		点火器	CDI unit	1	pcs	B
50QT-A-070500		喇叭	horn comp	1	pcs	B
50QT-A-070600		继电器	relay starting	1	pcs	B
50QT-A-070001		闪光器	flasher	1	pcs	B
50QT-A-070002		整流器	rectifier	1	pcs	B
50QT-A-070003		搭铁线	Iron cable	1	pcs	B
50QT-A-070004		电阻	resistor	1	pcs	B
50QT-A-070005		正极线	“+”cable	1	pcs	B
50QT-A-080000		全套标准件	whole standard piece	1	set	H
50QT-A-090010		扎带	wrap	1	set	B
50QT-A-090020		随车工具	tool with motorcycle	1	set	H
50QT-A-090030		全套贴花	Stickers	1	set	贴花
50QT-A-090040		铝牌	Aluminum plate	1	pcs	贴花
50QT-A-090050		防改牌	antitamper plate	1	pcs	贴花
50QT-A-090060		尾箱(选配)	Rear trunk	1	set	C
50QT-A-090060		防盗器(选配)	Burglar alarm	1	set	B
50QT-A-090070		防盗器压板(选配)	Burglar alarm press board	1	pcs	F
50QT-A-090080		单撑熄火开关(选配)	Kill switch(optional)	1	pcs	B

50QT-A-090090		碳罐组件(EPA)	carbon tin	1	set	A
---------------	-----------------------------------------------------------------------------------	-----------	------------	---	-----	---